

Broil King®

Broil King

REGAL XL
9572-42
9572-43
9572-82
9572-83





Broil King



REGAL XL SS
9573-42
9573-43
9573-82
9573-83



1





2






3

(2) 





4

(2) 




5


(1)




1




2




3







4







5




6










9



(2)  (2)



10



11






12

(4)



AA



PARTS LIST / LISTE DES PIECES

KEY #	ITEM #	DESCRIPTION	9572-42	9572-43	9572-82	9572-83	9573-42	9573-43	9573-82	9573-83
1	87109-931	PANEL - SIDE LEFT	1	1	1	1	1	1	1	1
2	87109-911	PANEL - SIDE RIGHT	1	1	1	1	1	1	1	1
3	27205-014	PANEL - FRONT INNER	1	1	1	1	1	1	1	1
3A	27203-014	PANEL - FRONT INNER	1	1	1	1	1	1	1	1
4	27205-924R	PANEL - INNER REAR	1	1	1	1	1	1	1	1
4A	27203-924R	PANEL - INNER REAR	1	1	1	1	1	1	1	1
5	27249-904	GREASE SHIELD	6	6	6	6	6	6	6	6
6	27005-91	HEAT SHIELD	3	3	3	3	3	3	3	3
6A	27003-91	HEAT SHIELD	3	3	3	3	3	3	3	3
7	Y-11544	SCREW - BURNER	6	6	6	6	6	6	6	6
8	S21242	CLIP - BURNER	6	6	6	6	6	6	6	6
10	82305-021R	PANEL - REAR COOKBOX	1	1	1	1	1	1	1	1
10A	82303-021R	PANEL - REAR COOKBOX	1	1	1	1	1	1	1	1
12	82315-021	PANEL - HOOD	1	1	1	1	1	1	1	1
12A	82313-021	PANEL - HOOD	1	1	1	1	1	1	1	1
18	22005-281	GRID	•	•	4	4	•	•	4	4
	22022-284	GRID	2	2	•	•	2	2	•	•
18A	22005-281	GRID	2	2	2	2	2	2	2	2
20	22005-991	WARMING RACK	1	1	1	1	1	1	1	1
20A	22003-991	WARMING RACK	1	1	1	1	1	1	1	1
22	22225-014	COLLECTOR BOX - LOWER	1	1	1	1	1	1	1	1
22A	22223-014	COLLECTOR BOX - LOWER	1	1	1	1	1	1	1	1
24	22215-014	COLLECTOR BOX - UPPER	1	1	1	1	1	1	1	1
24A	22213-014	COLLECTOR BOX - UPPER	1	1	1	1	1	1	1	1
25	22909-104D	BURNER	1	•	1	•	1	•	1	•
	22909-104E	BURNER	•	1	•	1	•	1	•	1
26	22001-769	CONTROL KNOB	6	6	6	6	6	6	6	6
26A	22001-669	CONTROL KNOB	2	2	2	2	2	2	2	2
27	22002-264	CONTROL BEZEL	6	6	6	6	6	6	6	6
27A	22001-164	CONTROL BEZEL	2	2	2	2	2	2	2	2
28	22008-884	CONTROL COVER	1	1	1	1	1	1	1	1
32	10111-15A	HOSE ASSEMBLY	1	1	1	1	1	1	1	1
34	S13473-073	HOSE-SIDE BURNER	1	•	1	•	1	•	1	•
	S13473-079	HOSE-SIDE BURNER	•	1	•	1	•	1	•	1
34A	Y-11230	COTTER PIN	1	1	1	1	1	1	1	1
35	29018-072	CONTROL ASSEMBLY	1	•	1	•	1	•	1	•
	29018-075	CONTROL ASSEMBLY	•	1	•	1	•	1	•	1
36	10342-T21	ELECTRODE – SIDE BURNER	1	1	1	1	1	1	1	1
37	20809-957	TUBE-REAR BURNER ASSY	1	1	1	1	1	1	1	1
38	Y-11990	HEX NUT	1	1	1	1	1	1	1	1
43	10342-E12	ELECTRODE	2	2	2	2	2	2	2	2
43A	10342-E22	ELECTRODE	1	1	1	1	1	1	1	1
44	10342-45	ELECTRONIC IGNITOR	1	1	1	1	1	1	1	1
44A	25070-93	IGNITOR BUTTON	1	1	1	1	1	1	1	1
44B	25070-92	IGNITOR WIRE	1	1	1	1	1	1	1	1
47	21035-991	GREASE RAIL	2	2	2	2	2	2	2	2
47A	21033-991	GREASE RAIL	2	2	2	2	2	2	2	2
48	22009-901	GREASE PAN	2	2	2	2	2	2	2	2
49	27055-901	GREASE TRAY	1	1	1	1	1	1	1	1
49A	27053-901	GREASE TRAY	1	1	1	1	1	1	1	1
51	22209-904	FLAV-R-WAVE ®	6	6	6	6	6	6	6	6
52	86101-631	LID END CAP - LEFT	1	1	1	1	1	1	1	1
53	86101-611	LID END CAP - RIGHT	1	1	1	1	1	1	1	1
54	86305-611	LID - OUTER PANEL	1	1	1	1	•	•	•	•
	86305-614	LID - OUTER PANEL	•	•	•	•	1	1	1	1
54A	86303-611	LID - OUTER PANEL	1	1	1	1	•	•	•	•
	86303-614	LID - OUTER PANEL	•	•	•	•	1	1	1	1
55	86205-61	LID - INNER PANEL	1	1	1	1	1	1	1	1
55A	86203-61	LID - INNER PANEL	1	1	1	1	1	1	1	1
56	24005-12A	HANDLE	1	1	1	1	1	1	1	1
56A	24003-12A	HANDLE	1	1	1	1	1	1	1	1
57	54009-936	BEZEL	4	4	4	4	4	4	4	4
59	10081-BK630	NAMEPLATE	2	2	2	2	2	2	2	2
60	10571-6	HEAT INDICATOR	2	2	2	2	2	2	2	2
65	20005-000	MATCH LIGHT - STICK	2	2	2	2	2	2	2	2
68	21175-111A	DOOR	1	1	1	1	•	•	•	•
	22275-114A	DOOR	•	•	•	•	1	1	1	1
69	21175-131A	DOOR	1	1	1	1	•	•	•	•
	22275-134A	DOOR	•	•	•	•	1	1	1	1
70	21071-13	HANDLE	3	3	3	3	3	3	3	3

PARTS LIST / LISTE DES PIECES

KEY #	ITEM #	DESCRIPTION	9572-42	9572-43	9572-82	9572-83	9573-42	9573-43	9573-82	9573-83
71	21070-13	BEZEL	6	6	6	6	6	6	6	6
78	21335-111	BRACKET - DOOR CATCH	1	1	1	1	1	1	1	1
78A	21333-921	BRACKET - DOOR CATCH	1	1	1	1	1	1	1	1
80	21109-905R	SIDE PANEL	3	3	3	3	3	3	3	3
82	25208-201R	SHELF - CABINET	1	1	1	1	1	1	1	1
88	21305-925R	PANEL - REAR	1	1	1	1	1	1	1	1
88A	25308-925R	PANEL - REAR	1	1	1	1	1	1	1	1
90	25098-935	BASE	1	1	1	1	1	1	1	1
100	21039-911	BRACKET - CASTOR SUPPORT	3	3	3	3	3	3	3	3
101	21039-301	TANK BRACKET	1	1	1	1	1	1	1	1
102	10892-23	CASTOR	3	3	3	3	3	3	3	3
102A	10892-285	CASTOR	3	3	3	3	3	3	3	3
110	23030-631	SHELF BRACKET - LEFT	2	2	2	2	2	2	2	2
111	23030-611	SHELF BRACKET - RIGHT	2	2	2	2	2	2	2	2
114	23101-614	SHELF - RIGHT	1	1	1	1	1	1	1	1
115	23100-654	SHELF- LEFT	1	1	1	1	1	1	1	1
116	23401-631	SHELF FRONT - LEFT	1	1	1	1	1	1	1	1
116A	23401-611	SHELF FRONT - RIGHT	1	1	1	1	1	1	1	1
117	23009-608	SHELF STRAP	2	2	2	2	2	2	2	2
123	Y-12117	LID CATCH PLUG	2	2	2	2	2	2	2	2
124	23000-271	SHELF-SIDE BURNER	1	1	1	1	1	1	1	1
125	23000-254	COVER-SIDE BURNER	1	1	1	1	1	1	1	1
126	10390-R81A	SIDE BURNER	•	1	•	1	•	1	•	1
	10390-R81D	SIDE BURNER	1	•	1	•	1	•	1	•
128	23009-98	GRID	1	1	1	1	1	1	1	1
130	27905-354E	BURNER ROTISSERIE	1	1	1	1	1	1	1	1
131	10693-095	REAR BURNER-ORIFICE	1	•	1	•	1	•	1	•
	10693-099	REAR BURNER-ORIFICE	•	1	•	1	•	1	•	1
133	S15271	HANDLE	1	1	1	1	1	1	1	1
134	S15270	BALANCER	1	1	1	1	1	1	1	1
135	S15299	WASHER	1	1	1	1	1	1	1	1
136	S15263	BUSHING	2	2	2	2	2	2	2	2
137	S15260	SPLIT ROD	1	1	1	1	1	1	1	1
138	S15287	4 PRONG FORKS	1	1	1	1	1	1	1	1
139	57039-901	ROTISSERIE BRACKET	1	1	1	1	1	1	1	1
140	S21125	SCREW #8 X 1/2	32	32	32	32	32	32	32	32
141	Y-12860	SCREW - 1/4-20 X1	4	4	4	4	4	4	4	4
143	Y-12855	SCREW 1/4-20 X 3/8	48	48	48	48	48	48	48	48
144	Y-12220	BUSHING	1	1	1	1	1	1	1	1
145	S21235	HINGE PIN	2	2	2	2	2	2	2	2
145A	10240-17	HINGE PIN	1	1	1	1	1	1	1	1
146	S21233	HITCH PIN CLIP	3	3	3	3	3	3	3	3
147	Y-11231	LID BUMPER	4	4	4	4	4	4	4	4
147A	Y-11235	LID BUMPER	8	8	8	8	8	8	8	8
148	10240-20	DOOR PIN	3	3	3	3	3	3	3	3
149	10240-19	DOOR PIN	3	3	3	3	3	3	3	3
150	Y-12124	DOOR PIN CAP	3	3	3	3	3	3	3	3
151	Y-12310	SCREW 1/4-20 X 3/4	4	4	4	4	4	4	4	4
152	Y-12222	MAGNET	3	3	3	3	3	3	3	3
153	Y-12223	SNAP IN MAGNET	3	3	3	3	3	3	3	3
154	Y-11560	SCREW 1/4-20 X 1-1/2	12	12	12	12	12	12	12	12
155	S21124	SCREW #8 X 1/2	36	36	36	36	36	36	36	36
156	Y-11793	NUT 1/4-20	38	38	38	38	38	38	38	38
157	Y-12835	SCREW #6-32 X 1/4	2	2	2	2	2	2	2	2
158	Y-12646	SCREW - SHOULDER #8 X 1/2	2	2	2	2	2	2	2	2
159	S21136	SCREW #8-32 X 3/8	16	16	16	16	16	16	16	16
160	Y-29304	SCREW #10-24 X 3/8	50	50	50	50	50	50	50	50
161	Y-29310	SCREW #10-24 X 3/4	4	4	4	4	4	4	4	4
162	S35095	SCREW #10-24 X 5/9	2	2	2	2	2	2	2	2
163	S35094	SCREW #10-24 X 5/8	2	2	2	2	2	2	2	2
165	Y-12127	DOOR CLIP	3	3	3	3	3	3	3	3
166	Y-11981	SCREW 1/4-20 X 3/4	28	28	28	28	28	28	28	28
169	S21061	WING NUT	2	2	2	2	2	2	2	2
171	S15246	MOTOR	1	1	1	1	1	1	1	1
173	S21362	SPRING	1	1	1	1	1	1	1	1
180	Y-12857	WASHER	6	6	6	6	6	6	6	6
181	25030-73	WIRE - BATTERY PACK	1	1	1	1	1	1	1	1
181A	25070-95	SWITCH - LED LIGHTS	1	1	1	1	1	1	1	1
184	25080-80	BATTERY PACK - LED LIGHTS	1	1	1	1	1	1	1	1
186	Y-12865	SCREW 1/4-20 X 3/4	51	51	51	51	51	51	51	51
193	25020-84	WIRE - LED LIGHTS	2	2	2	2	2	2	2	2

