



Broil King®



Broil King
MONARCH 320
8342-52
8342-53
















Broil King
MONARCH 340
8342-62
8342-63




Broil King
MONARCH 390
8342-82
8342-83



HARDWARE INCLUDED / MATERIAL INCLUS / EQUIPOS INCLUIDO







S21420		X2	S21124		X2
Y-12865		X8	Y-11793		X2
Y-12222		X1	Y-11563		X8
Y-12124		X1	AAA		X1
Y-29304		X2	Y-12223		X1
Y-11551		X1	Y-12673		X2
	 <p>#3 ROBERTSON</p> <p>#2 ROBERTSON</p>				

TOOLS REQUIRED / OUTILS NECESSAIRES / HERRAMIENTAS NECESARIAS






1


- (2) 
- (2) 
- (1) 




2




3


(8) 




4





5


(2) 





6




7





8










10







11

(1)






12

(1)










13

(1)





14


(2)  (2) 




15


(2)










18







20



21



PARTS LIST / LISTE DES PIECES

<u>KEY #</u>	<u>ITEM #</u>	<u>DESCRIPTION</u>	<u>8342-52</u>	<u>8342-53</u>	<u>8342-62</u>	<u>8342-63</u>	<u>8342-82</u>	<u>8342-83</u>
1	10909-E340A	CASTING BOTTOM	1	1	1	1	1	1
2	10473-E341	CASTING TOP	1	1	1	1	1	1
3	10081-BK630	NAMEPLATE	1	1	1	1	1	1
4	10958-E340A	TOP CASTING INSERT	1	1	1	1	1	1
5	10571-6	HEAT INDICATOR	1	1	1	1	1	1
6	10240-15	HINGE PIN	2	2	2	2	2	2
6A	S21237	HINGE SPACER	2	2	2	2	2	2
7	S21233	HITCH PIN CLIP	2	2	2	2	2	2
8	Y-11544S	SCREW - BURNER	3	3	3	3	3	3
8A	S21242	HITCH PIN CLIP	3	3	3	3	3	3
9	10225-T356	GRID	2	2	2	2	2	2
10	10222-E400	FLAV-R-WAVE™	3	3	3	3	3	3
11	10225-E341	GRID - WARMING RACK	1	1	1	1	1	1
12	10222-E301	DIVIDER	2	2	2	2	2	2
13	10184-R83	BOSS EXTENSION	1	1	1	1	1	1
15	10390-E20D	BURNER	3	•	3	•	3	•
	10390-E20E	BURNER	•	3	•	3	•	3
17	10342-245	ELECTRONIC IGNITOR	1	1	•	•	•	•
	10342-246	ELECTRONIC IGNITOR	•	•	1	1	•	•
	10342-247	ELECTRONIC IGNITOR	•	•	•	•	•	•
18	10342-E12	ELECTRODE	2	2	2	2	2	2
19	52224-224A	COLLECTOR BOX	1	1	1	1	1	1
20	10111-16A	HOSE	1	1	1	1	1	1
21	29004-012	CONTROL ASSEMBLY	1	•	•	•	•	•
	29004-013	CONTROL ASSEMBLY	•	1	•	•	•	•
	29004-032	CONTROL ASSEMBLY	•	•	1	•	•	•
	29004-033	CONTROL ASSEMBLY	•	•	•	1	•	•
	29004-072	CONTROL ASSEMBLY	•	•	•	•	1	•
	29004-073	CONTROL ASSEMBLY	•	•	•	•	•	1
21A	S13470-073	HOSE-SIDE BURNER	•	•	1	•	1	•
	S13470-079	HOSE-SIDE BURNER	•	•	•	1	•	1
21B	Y-11230	COTTER PIN	•	•	1	1	1	1
21C	10110-34	TUBE-REAR BURNER ASSY	•	•	•	1	1	1
23	10472-K431	CONTROL KNOB	3	3	4	4	5	5
30	10194-F138	CONTROL COVER	1	1	•	•	•	•
	10194-F158	CONTROL COVER	•	•	1	1	•	•
	10194-F198	CONTROL COVER	•	•	•	•	1	1
31	10711-E34	EDGE CAP	1	1	1	1	1	1
32	10711-E33	EDGE CAP	1	1	1	1	1	1
33	10184-E96	RADIATION SHIELD	1	1	1	1	1	1
34	10184-E97	GREASE RAIL	1	1	1	1	1	1
35	10184-E501	SUPPORT-CASTING-LEFT	1	1	1	1	1	1
36	10184-E511	SUPPORT-CASTING-RIGHT	1	1	1	1	1	1
37	10184-E651	SUPPORT-SIDE SHELF	2	2	2	2	2	2
37A	10184-E62	SUPPORT-SIDE SHELF	2	2	2	2	2	2
38	10184-E641	SUPPORT-SIDE SHELF	2	2	2	2	2	2
38A	10184-E63	SUPPORT-SIDE SHELF	2	2	2	2	2	2
39	10956-E421	BRACE-REAR	1	1	1	1	1	1

PARTS LIST / LISTE DES PIECES

<u>KEY #</u>	<u>ITEM #</u>	<u>DESCRIPTION</u>	<u>8342-52</u>	<u>8342-53</u>	<u>8342-62</u>	<u>8342-63</u>	<u>8342-82</u>	<u>8342-83</u>
40	10958-E71	BASE	1	1	1	1	1	1
41	10956-E311	BRACE-FRONT	1	1	1	1	1	1
43	10958-E761	SIDE PANEL	2	2	2	2	2	2
44	10958-E361	PANEL - REAR	1	1	1	1	1	1
45	10184-E981	BRACKET - DOOR CATCH	1	1	1	1	1	1
48	10184-E691	BRACKET - SHELF	2	2	2	2	2	2
50	10711-E821	SHELF	1	1	1	1	1	1
51	10711-E821	SHELF	•	•	•	•	•	•
	10711-E831	SHELF	1	1	•	•	•	•
56	10892-7G	WHEEL	2	2	2	2	2	2
60	10711-E49	END CAP - SHELF	2	2	2	2	2	2
66	S13006A	BURNER ROTISSERIE	•	•	•	•	•	•
67	21070-13	BEZEL	2	2	2	2	2	2
68	S21362	SPRING	•	•	•	•	•	•
69	10958-E48AB	DOOR	1	1	1	1	1	1
70	21071-13	HANDLE	1	1	1	1	1	1
71	10696-085	REAR BURNER-ORIFICE	•	•	•	•	•	•
	10696-094	REAR BURNER-ORIFICE	•	•	•	•	•	•
72	S21420	PUSH NUT	2	2	2	2	2	2
73	Y-11990	HEX NUT	•	•	•	•	•	•
75	24009-12A	HANDLE	1	1	1	1	1	1
77	Y-12857	WASHER	2	2	2	2	2	2
78	10892-13	CASTOR	2	2	2	2	2	2
79	Y-11563	SCREW #14-10 X 1 3/4	8	8	8	8	8	8
80	Y-11546	SCREW 1/4-20 X 5/8	8	8	8	8	8	8
81	Y-12860	SCREW 1/4-20 X 1 3/8	4	4	4	4	4	4
82	Y-12673	SHELF - LOCK PIN	2	2	2	2	2	2
83	Y-12865	SCREW 1/4-20 X 1/2	10	10	10	10	10	10
84	S15170	AXLE	1	1	1	1	1	1
85	Y-12855	SCREW 1/4-20 X 3/8	7	7	7	7	7	7
86	10184-E09	HEAT SHIELD	1	1	1	1	1	1
87	Y-11793	NUT 1/4-20	16	16	16	16	16	16
96	S21125	SCREW #8 X 3/8	4	4	4	4	4	4
97	Y-11545	SCREW 1/4-20 X 1 3/8	4	4	4	4	4	4
98	S21124	SCREW #8 X 1/2	27	27	28	28	29	29
99	Y-12646	SCREW #8 X 1/2	•	•	2	2	2	2
104	Y-12835	SCREW #6-32 X 1/4	•	•	2	2	2	2
105	Y-12853	WASHER	•	•	2	2	2	2
106	Y-12861	CAP SCREW 1/4-20 X 3/8	•	•	2	2	2	2
107	Y-12863	WASHER	•	•	4	4	4	4
110	53140-981	GRID	•	•	1	1	1	1
111	10390-E10	SIDE BURNER	•	•	1	1	1	1
113	10342-T16	ELECTRODE	•	•	1	1	1	1
114	23000-251	COVER-SIDE BURNER	•	•	1	1	1	1
115	Y-29304	SCREW #10-24 X 3/8	2	2	2	2	2	2
117	23000-271	SHELF-SIDE BURNER	1	1	1	1	1	1
122	57054-901	GREASE TRAY	1	1	1	1	1	1
123	52009-901	GREASE PAN	1	1	1	1	1	1

PARTS LIST / LISTE DES PIÈCES

<u>KEY #</u>	<u>ITEM #</u>	<u>DESCRIPTION</u>	<u>8342-52</u>	<u>8342-53</u>	<u>8342-62</u>	<u>8342-63</u>	<u>8342-82</u>	<u>8342-83</u>
135	Y-12119	BUSHING	2	2	3	3	3	3
136	10184-E44	ROTISSERIE SHIELD	1	1	1	1	1	1
137	10184-E42	ROTISSERIE BRACKET	1	1	1	1	1	1
138	10184-E43	ROTISSERIE SHIELD	1	1	1	1	1	1
139	S21061	WING NUT	2	2	2	2	2	2
140	Y-29306	SCREW #10-24 x 3/4	2	2	2	2	2	2
141	S15271	HANDLE	•	•	•	•	•	•
142	S15270	BALANCER	•	•	•	•	•	•
143	S15263	BUSHING	•	•	•	•	•	•
144	Y-12220	BUSHING	•	•	1	1	1	1
145	S15264	SPIT ROD	•	•	•	•	•	•
146	S15246	MOTOR	•	•	•	•	•	•
147	S15299	WASHER	•	•	•	•	•	•
148	S15287	4 PRONG FORKS	•	•	•	•	•	•
149	10240-20	DOOR PIN	1	1	1	1	1	1
152	Y-12222	MAGNET	1	1	1	1	1	1
153	Y-12223	SNAP IN MAGNET	1	1	1	1	1	1
156	Y-12310	SCREW 1/4-20 X 3/4	2	2	2	2	2	2
164	Y-12124	DOOR PIN CAP	1	1	1	1	1	1
165	Y-11551	SCREW 1/4-20 X 1	1	1	1	1	1	1
166	Y-12117	BUSHING	•	•	2	2	2	2

