

Broil King®



Broil King

REGAL 440

9962-62

9962-63

9992-63



Broil King

REGAL S 440

9963-22

9963-23



Broil King

REGAL 490

9962-82

9962-83



Broil King

REGAL S 490

9963-42

9963-43









9963-46

9963-82


9963-83

9963-86



HARDWARE INCLUDED

Y-12865		(26)	S21124		(8)
S21125		(4)	Y-12222		(2)
Y-29304		(6)	Y-12223		(2)
S21233		(2)	Y-11560		(4)
S21235		(2)	Y-11793		(8)
					


TOOLS REQUIRED




1





2





(4)





(4)



3




4





5

(4) 




6

(6)




7




8


(2) 




9





10



(2) 



11




12






13



(4)






(4)













16




17




18




1





2








3




4














22

(1)  (1)





24



PARTS LIST / LISTE DES PIÉCES

	KEY #	ITEM #	DESCRIPTION	9962-62	9962-63	9992-63	9962-82	9962-83	9963-22	9963-23	9963-42	9963-43	9963-46	9963-82	9963-83	9963-88
1		27005-003	FIRE BOX	1	1	1	1	1	1	1	1	1	1	1	1	1
2		86005-301	LID	1	1	1	1	•	•	•	•	•	•	•	•	•
		86005-303	LID	•	•	•	•	1	1	1	1	1	1	1	1	1
5		27249-904	GREASE SHIELD	4	4	4	4	4	4	4	4	4	4	4	4	4
7		Y-11544S	BURNER SCREW	4	4	4	4	4	4	4	4	4	4	4	4	4
8		S21242	CLIP	4	4	4	4	4	4	4	4	4	4	4	4	4
18		22005-281	GRID - CI	4	4	4	4	•	•	•	•	•	•	•	•	•
		22022-284	GRID - SS WIRE	•	•	•	•	2	2	2	2	2	2	•	•	•
20		22005-991	WARMING RACK	1	1	1	1	1	1	1	1	1	1	1	1	1
22		22025-904	COLLECTOR BOX	1	1	1	1	1	1	1	1	1	1	1	1	1
25		22909-104D	BURNER	4	•	•	4	•	4	•	4	•	•	4	•	•
		22909-104E	BURNER	•	4	4	•	4	•	4	•	4	•	•	4	•
		22909-NGE	BURNER	•	•	•	•	•	•	•	•	•	4	•	•	4
26		22001-769	CONTROL KNOB	4	4	4	4	4	4	4	4	4	4	4	4	4
26A		22001-669	CONTROL KNOB	1	1	1	2	1	1	1	2	2	2	2	2	2
27		22002-264	CONTROL BEZEL	4	4	4	4	4	4	4	4	4	4	4	4	4
27A		22001-164	CONTROL BEZEL	1	1	1	2	1	1	1	2	2	2	2	2	2
28		22005-813	CONTROL COVER	•	•	•	•	•	•	•	•	•	•	•	•	•
		22005-833	CONTROL COVER	1	1	1	•	1	1	1	•	•	•	•	•	•
		22005-883	CONTROL COVER	•	•	•	1	•	•	1	1	1	1	1	1	1
32		10111-15A	HOSE	1	1	1	1	1	1	1	1	1	1	1	1	1
34		S13473-073	HOSE-SIDE BURNER	1	•	•	1	1	•	1	•	•	•	1	•	•
		S13473-079	HOSE-SIDE BURNER	•	1	1	1	•	1	1	1	1	•	1	•	1
		S13473-109	HOSE-SIDE BURNER	•	•	•	•	•	•	•	•	•	1	•	•	1
34A		Y-11230	CLIP	1	1	1	1	1	1	1	1	1	1	1	1	1
35		29005-012	CONTROL ASSEMBLY	•	•	•	•	•	•	•	•	•	•	•	•	•
		29005-015	CONTROL ASSEMBLY	•	•	•	•	•	•	•	•	•	•	•	•	•
		29005-032	CONTROL ASSEMBLY	1	•	•	•	1	•	•	•	•	•	•	•	•
		29005-035	CONTROL ASSEMBLY	•	1	1	•	•	•	1	•	•	•	1	•	•
		29005-072	CONTROL ASSEMBLY	•	•	•	1	•	•	•	•	•	•	•	•	•
		29005-075	CONTROL ASSEMBLY	•	•	•	1	•	•	•	•	1	•	•	1	•
		29005-076	CONTROL ASSEMBLY	•	•	•	•	•	•	•	•	•	1	•	•	1
36		10342-T18	ELECTRODE – SIDE BURNER	1	1	1	1	1	1	1	1	1	1	1	1	1
37		20809-957	REAR BURNER GAS TRAIN	•	•	•	1	1	•	1	1	1	1	1	1	1
38		Y-11990	NUT - REAR BURNER	•	•	•	1	1	•	1	1	1	1	1	1	1
43		10342-E13	ELECTRODE	2	2	2	2	2	2	2	2	2	2	2	2	2
44		10342-42	ELECTRONIC IGNITOR - DOUBLE	•	•	•	•	•	•	•	•	•	•	•	•	•
		10342-43	ELECTRONIC IGNITOR - TRIPLE	1	1	1	•	1	1	1	•	•	•	•	•	•
		10342-44	ELECTRONIC IGNITOR - QUAD	•	•	•	1	•	•	•	1	1	1	1	1	1
44A		25070-92	IGNITOR WIRE HARNESS	1	1	1	1	1	1	1	1	1	1	1	1	1
44B		25070-93	IGNITOR BUTTON	1	1	1	1	1	1	1	1	1	1	1	1	1
47		21035-991	GREASE RAIL	2	2	2	2	2	2	2	2	2	2	2	2	2
48		22009-901	GREASE PAN	1	1	1	1	1	1	1	1	1	1	1	1	1
49		27055-901	GREASE TRAY	1	1	1	1	1	1	1	1	1	1	1	1	1

PARTS LIST / LISTE DES PIÈCES


KEY #		ITEM #	DESCRIPTION	9962-62	9962-63	9992-63	9962-63	9962-82	9962-83	9963-22	9963-23	9963-42	9963-43	9963-46	9963-82	9963-83	9963-88
51	22209-903	FLAV-R-WAVE®	4	4	4	4	4	4	4	4	4	4	4	4	4	4	4
56	24005-12A	HANDLE	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
58	54009-936	HANDLE - BEZEL	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2
59	10081-BK630	NAMEPLATE	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
60	10571-6	HEAT INDICATOR	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
65	20005-000	MATCH LIGHT - STICK	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
68	23275-111A	DOOR	1	1	1	1	1	1	1	•	•	•	•	•	•	•	•
69	23275-113A	DOOR	•	•	•	•	•	1	1	1	1	1	1	1	1	1	1
	23275-131A	DOOR	1	1	1	1	1	1	1	•	•	•	•	•	•	•	•
	23275-133A	DOOR	•	•	•	•	•	1	1	1	1	1	1	1	1	1	1
70	21071-13	HANDLE	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2
71	21070-13	HANDLE - BEZEL	4	4	4	4	4	4	4	4	4	4	4	4	4	4	4
78	21335-111	BRACKET - DOOR CATCH	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
80	21109-901R	SIDE PANEL	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2
82	25208-201	CABINET SHELF	1	1	1	1	1	1	1	1	1	1	1	•	1	1	•
83	21036-901	CABINET SHELF SUPPORT	1	1	1	1	1	1	1	1	1	1	1	•	1	1	•
88	21305-921R	PANEL - REAR	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
90	21795-931	BASE	1	1	1	1	1	1	1	1	1	1	1	•	1	1	•
	21795-951	BASE	•	•	•	•	•	•	•	•	•	•	•	1	•	1	1
100	21039-911	BRACKET – CASTOR SUPPORT	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2
101	21039-301	LOWER TANK SUPPORT	1	1	1	1	1	1	1	1	1	1	1	•	1	1	•
102	10892-23	CASTOR	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2
102A	10892-285	CASTOR	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2
114	23101-113	SHELF	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
115	23101-153	SHELF - SB	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
123	Y-12117	SIDE BURNER LID STOP	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2
124	23000-271	SHELF-SIDE BURNER	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
125	23000-253	COVER-SIDE BURNER	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
126	10390-R81A	SIDE BURNER	•	1	1	1	1	1	1	•	1	1	1	1	•	1	1
	10390-R81D	SIDE BURNER	1	•	1	1	1	1	1	1	1	1	1	•	1	1	•
128	23009-99	GRID	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
130	27905-354	REAR BURNER	•	•	•	•	•	1	1	•	1	1	1	1	1	1	1
131	10693-099	REAR BURNER ORIFICE	•	•	•	•	•	1	1	•	•	1	1	•	1	1	•
	10693-161	REAR BURNER ORIFICE	•	•	•	•	•	•	•	•	•	•	•	1	•	1	1
133	S15271	ROTISSERIE HANDLE	•	•	•	•	•	1	1	•	•	1	1	1	•	1	1
134	S15270	ROTISSERIE COUNTER BALANCE	•	•	•	•	•	1	1	•	•	1	1	1	1	1	1
135	S15299	ROTISSERIE WASHER	•	•	•	•	•	1	1	•	•	1	1	1	1	1	1
136	S15263	ROTISSERIE BUSHING	•	•	•	•	•	1	1	•	•	1	1	1	1	1	1
137	S15256	ROTISSERIE SPIT ROD	•	•	•	•	•	1	1	•	•	1	1	1	1	1	1
138	S15287	ROTISSERIE FORK	•	•	•	•	•	2	2	•	•	2	2	2	2	2	2
139	57039-901	ROTISSERIE BRACKET	•	•	•	•	•	1	1	•	•	1	1	1	1	1	1
140	S21125	SCREW # 8 X 1/2	4	4	4	4	4	4	4	4	4	4	4	4	4	4	4
141	Y-12860	SCREW	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2
144	Y-12220	BUSHING	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1

33-86 2 2 2 2 2 2 2 4 2 2 2 8 14 8 4 4 2 2 12 2 2 4 4 1 1 2 2 1 1 1 1 1 2 2 1 1 1 1 1 32 • 1 1 1 2

25



(2)



(2)

